



### **Instructions for patching and or repair:**

1. Mix one part cement (white, gray or a combination of the two depending on the design mix) with three parts concrete sand.
2. Mix one part acrylic bonder with three parts water: add this to the cement/sand mixture to form a thick paste.
3. Wet down the area to be repaired
4. Mix a very small amount of the correct pigment (color) into the san/cement/water paste until it matches the color of the area to be repaired.
5. Apply the mix to the area to be repaired with a putty knife or trowel and build it up to the approximate shape. Cover repair with clear plastic and let dry for 24 hours. Sand and file to get desired shape/finish.
6. Repeat process as necessary.

Aristone Concrete Designs Contact:  
Charles D. Martin  
1-(480) 967-3035(ph) 1-(480) 967-1181 (fax)  
e-mail: [charlie@aristonedesigns.com](mailto:charlie@aristonedesigns.com)